

207 Ceramic XHT Fluid

- Solvent free epoxy repair fluid
- High abrasion & wear resistant coating
- Suitable for immersion up to 180°C/356°F

Cure Times

At 20°C (68F°) the product will have the following cure times –

Usable Life 90mins
Minimum overcoat

3 hours

Maximum overcoat

24 hours

Full cure Requires heat cure, please refer to Resimac Technical dept for more details

Coverage Rates

1kg (2.2lb) of product will give the following coverage rates –
2.48m² at 300 microns
26.7ft² at 12mil

Please note that the coverage rates quoted are theoretical and do not take into consideration the profile or condition of the surface being repaired.

Colour

Mixed material –

Grey liquid

Base component –

Grey paste

Activator component –

Amber liquid

Typical Application

Condensate pumps

Distillation units

Return tanks

Calorifiers

Evaporators

Heat exchangers

Scrubber units

Technical specifications and characteristics

Mixing ratios By weight 4.8:1
By volume 3.28:1

Volume capacity 746cc/kg

Surface Preparation

Metallic Substrates – Abrasive blast cleaning

1. All oil and grease must be removed from the surface using an appropriate cleaner such as MEK.
2. All surfaces must be abrasive blasted to **ISO 8501/4 Standard SA2.5 (SSPC SP10/NACE 2)** minimum blast profile of 75 microns (3mil) using an angular abrasive.
3. Once blast cleaned, the surface must be degreased and cleaned using MEK or similar type material.
4. All surfaces must be coated before ginging or oxidation occurs.

PLEASE NOTE: For salt contaminated surfaces the substrate must be pressure washed with clean water and checked for salt contamination, please refer to the surface preparation and pre-application guide for further information.

Over-coating times

Minimum - the applied material can be over-coated as soon as it is touch dry.
Maximum - the over-coating time should not exceed 24 hours at 20°C (68F°).
Where the maximum over-coating time is exceeded, the material should be allowed to harden before being abraded or flash blasted

Mixing and Application

STEP 1

Ensure you have 1 x base unit, 1 x activator unit, 1 x spatula, 1 x brush and 1 x wft gauge



STEP 2

Open the activator tin and pour Contents into the base unit



STEP 3

Mix the two components using the spatula provided, ensure any unmixed material around the edges is mixed



STEP 4

To ensure the product is fully mixed check the material for any colour difference. The mixed material should be a consistent mix



STEP 5

Once the material is fully mixed use a brush to apply the coating to the repair surface. Care must be taken to ensure wet film thickness does not exceed 300 microns

